## CSP-255/275/295/295GP PROGRAM INSTALLATION GUIDE

## PREPARATION

- 1. Use the USB memory that has more than the install data file size.
- 2. Copy the install data file to the root of the USB memory.

model	Install data file
CSP-255	CSP-255SETUP.PRG
CSP-275	CSP-275SETUP.PRG
CSP-295	CSP-295SETUP.PRG
CSP-295GP	CSP-295GPSETUP.PRG


## **•INSTALLATION PROCEDURE**

[Note]Do not turn the power off and do not remove the media during the installation.


- 1. Turn the power switch on with holding down [FUNCTION] switch.
  - The Stream Lights of the  $B \triangleright -1$  key light continuously.




2. Insert the USB memory including the install data to the USB to DEVICE terminal.




• The Stream Lights of the  $B \triangleright -1$  key flash in succession in a downward pattern.



- When the preparation of installation has been completed, it will see the following screen is displayed.
  - The Stream Lights of the A-1, B-1 keys light continuously.



- 4. Press the [FUNCTION] switch or the B-1 key, then start program upgrading.
  - the progress display will appear.



- 5. When the installation has been completed, it will see the following screen is displayed.
  - The Stream Lights of the  $B \triangleright -1$  key light continuously.




6. Power off the instrument.

## TROUBLESHOOTING

If an error occurs, it will see the following screen is displayed.

• The Stream Lights of the B-1 key light continuously.



You need to reinstall the program. Go back to the beginning and follow the instruction again.